November 2014
900627-001 Rev 01

TouchTunes Karaoke Kit Readme

IMPORTANT! READ THIS BEFORE VISITING A LOCATION

It is important to understand the following Karaoke requirements before visiting a location to install equipment.

1 - A network running DHCP is required for each location using the Karaoke Service

The Karaoke Kit does not include a network switch or router. It also doesn't include any long CAT-5 Ethernet cables to connect the Media Player and the Wireless Microphone receiver. You will have to provide these cables, cut to the appropriate lengths.

1. If your location has a network but currently does not have any open network ports, you will be required to install a network switch.
2. If your location has a network, but is not running DHCP, you will be required to install a router with a connection for the jukebox and Media Player.
3. If your location has no network (i.e., wireless Internet), you will be required to install a router with a connection for the jukebox and Media Player.

2 - The Karaoke Service requires a signed Addendum to your Music Service Agreement

The Karaoke Service is only available to your jukeboxes after you have returned a signed Karaoke Service Addendum to TouchTunes. Once this Addendum has been processed, you do not need to contact TouchTunes if you add new jukeboxes to your route - they will automatically be capable of running the Karaoke Service once you have fulfilled the remaining requirements below.

3 - The Karaoke Service must be turned ON for each jukebox individually

After you have signed the Karaoke Addendum, the service becomes available to your current and future jukeboxes, but locations cannot switch into Karaoke mode unless you have accessed the jukebox from its Operator Menu or Operator Dashboard and set Karaoke to ON. This does not switch the jukebox to Karaoke mode, but allows the location to do so themselves as required. In addition to turning Karaoke ON, you will need to have done the following:

- Set up the Karaoke equipment, including the wireless microphone receiver, the Media Player (and a DHCP network If that was not already setup).
- Played a Karaoke song and adjusted the sound levels for both microphones.

To obtain a copy of the Karaoke addendum required to use the Karaoke service, contact your TouchTunes Sales Representative.

For technical questions regarding TouchTunes Karaoke, please contact TouchTunes Technical Support at 1-847-353-1954.